

AXEL

PLASTICS RESEARCH LABORATORIES, INC.
MOLD RELEASES & PROCESS ADDITIVES

50 Cambridge Drive, Monroe, CT 06468

Phone: 718-672-8300 • Fax: 718-565-7447
E-mail: info@axelplastics.com

www.axelplastics.com

Technical Data Sheet

XTEND™
Semi-Permanent Mold Releases

875R

Product Description

External mold release: An air-drying reactive resin solution that cures to provide a durable semi-permanent coating. Permits multiple releases without transfer at both ambient and elevated temperatures.

Composition

Proprietary resin solution in a hydrocarbon solvent blend.

Handling

MOISTURE SENSITIVE. KEEP TIGHTLY SEALED.
Minimize exposure to atmosphere.
Do not return exposed material to can.
Store above freezing and below 100°F/38°C.
DO NOT DILUTE

Features

Easy, wipe on
No WIPE OFF OR polishing required
High Gloss

Uses

Polyurethane resins.

Typical Properties

Effective Ingredients	< 1%
Color	Clear/straw
Specific Gravity	0.720 @25°C
Flash Point	<73°F / <23°C (C.O.C.)
Shelf Life	12 months in original unopened package
Solvents	Aliphatic Hydrocarbon Blend

Mold Preparation

Mold surfaces should be clean and free of previously used mold releases and other surface contaminants.

Application Instructions

Hand Wiping

Apply with a clean, woven, lint free cloth, such as the Scott Shop Towels On A Roll®, Kimberly-Clark WorkHorse® rags or WypAll® wipes, or a heavy-duty plain white paper towel.

Wet the cloth with release until it is damp but not dripping. Wipe onto mold surface using smooth even strokes. Apply a thin, uniform coating and allow the release to evaporate. Do not overwork the area or continue to wipe. Simply wipe on, and allow to dry.

Spraying:

Some molders prefer to apply the semi-permanent release with a hand pump spray bottle. Using this method, a 2 – 3 square foot area can be misted and then lightly wiped with a clean cloth to distribute the release consistently across the surface.

1) When working on a large surface area, apply to one section at a time, working from one end of the tool surface to the other. Natural bristle brushes and most foam paint applicators can also aid in smoothing out the coatings or working them into textured or hard to reach areas. When working with sprayers or brushes, avoid pooling the release in any one area.

2) 4 coats of release are recommended for a clean well-conditioned tool. At least 2 coats of Xtend XTR sealer are recommended for new, reconditioned or very difficult molds.

3) Allow approximately 3-5 minutes for each coat of release to dry and cure before applying the next coat. Low ambient temperatures (below 70°F / 20°C) may necessitate longer cure times.

4) Always use a fresh, clean cloth for each coat of release. If streaking occurs, replace your cloth with a clean one. Also make sure that the cloth is not too saturated, as heavy applications of release can streak (see FAQ's Semi-Permanent Mold Releases & FRP Molds). Most streaks can be removed by waiting for the release to cure and then lightly buffing the surface with a clean, dry cloth.

5) To maximize productivity, a break-in procedure can be beneficial. A good method is to apply a light re-wipe of release to the mold surface following the first pull, another after the third, and another after the fifth part. It is also a good idea to do more frequent touch ups on sheer edges, radius areas, and high wear sections. This will improve release performance and provide the best protection for your tool.

* Due to the unique properties of this material, we require a clean closed application container. The container we find best suited, is a HDPE bottle with a shampoo squeeze style cap, where only a small amount of air is transferred. Gallons should be transferred into the type of container described above. At your request we can supply a sample and source. Drum quantity customers are required to use a desiccant drier attachment to assure proper release performance.

AXEL

PLASTICS RESEARCH LABORATORIES, INC.
MOLD RELEASES & PROCESS ADDITIVES

Mailing: Box 77 0855 Woodside, NY 11377 USA
Shipping: 58-20 Broadway, Woodside, NY 11377 USA
Phone: 718-672-8300 • Fax: 718-565-7447
E-mail: info @axelplast.com

www.axelplastics.com

Technical Data Sheet

XTENDTM
Semi-Permanent Mold Releases

875R

Maintenance

Reapply mold release as necessary. CX-500 cleaner may be used to remove minor buildup, which occurs during molding. Reapply 875R release after using cleaner.

XTEND, MoldWiz & PasteWiz are registered trademarks of Axel plastics Research Laboratories.

This information is supplied for technically skilled professionals working at their own risk. Axel believes the information to be accurate, although the Company assumes no liability in the validity of this information for any specific process or application. Moreover, Axel will assume no liability from any direct and/or consequential damages of any kind that may arise from the use or non use of Axel products or information supplied by the Company or its appointed representatives.

120424